


GB



VEX4000
RANGE
MODULES

EXcon handheld terminal

Menus and alarms

VEX5000



Original instructions

1. The handheld terminal		
	1.1. Operation	4
	1.1.1. Operation and functions.....	4
	1.1.2. Operating levels	5
	1.2. Passwords	5
2. User mode		
	2.1. User menu	6
	2.1.1. Fan operation.....	7
	2.1.2. Extended operation.....	8
	2.1.3. Temperature.....	8
	2.1.4. Time and date.....	9
	2.1.5. Alarm log.....	9
	2.1.6. About the control system.....	9
	2.1.7. Internet.....	10
3. Installer level		
	3.1. Installer menu	11
	3.1.1. Fan operation.....	12
	3.1.2. Temperature.....	15
	3.1.3. Initial adjustment.....	17
	3.1.4. Fire.....	18
	3.1.5. Communication.....	19
	3.1.6. Language.....	19
	3.1.7. Factory setting.....	20
	3.1.8. Store functions.....	21
4. Service level		
	4.1. Service menu	24
	4.1.1. Fan.....	25
	4.1.2. Filter.....	28
	4.1.3. Heating.....	30
	4.1.4. Heating recovery.....	35
	4.1.5. Cooling.....	38
	4.1.6. Damper.....	42
	4.1.7. Temperature sensor correction.....	44
	4.1.8. Pressure transmitter.....	45
5. Alarm summary		
	Alarm list manual terminal	46

Symbols and terms

Prohibition symbol



Failure to observe instructions marked with a prohibition symbol may result in serious or fatal injury.

Danger symbol



Failure to observe instructions marked with a danger symbol may result in personal injury and/or damage to the unit.

Terms

These instructions use the following terms for air flows as given in DS447-2013:

- Supply air
- Extract air
- Outdoor air
- Exhaust air
- Recirculation

Screen displays

These guidelines contain screen displays intended to help the user and indicate which menu the user is currently viewing.

NB:

The order of screen displays/menus depends on the VEX units settings. Therefore there may be discrepancies between the order of screen displays in the guidelines and in the VEX unit's handheld terminal.

Software version

Software version

These instructions are for use with the following version:

- EXcon Master SW: 3.19
- Handheld terminal SW: 1.04

The current software version for both the EXcon Master and the handheld terminal can be seen in the menu: **User > On control** of the handheld terminal.

1. The handheld terminal

1.1 Operation

Functional description

Reading, programming and control can be performed from the handheld terminal. The terminal has a graphic display, a button with PRESS and TURN function, a "?" (help)-button and an "Esc" button.

The handheld terminal menu and settings are structured to correspond to the menu and settings found in the EXcon control system's web server. The functionality, settings, etc. of the EXcon control system are described in the EXcon instructions.

Handheld terminal

A	Graphic display	
B	Light diode: Green LED which lights up when voltage on the handheld terminal is OK.	
C	Light diode: Red LED which flashes in the event of an alarm from the unit or the system alarms.	
D	PRESS button	
E	TURN button	
F	? button	
G	ESC button	

1.1.1 Operation and functions

TURN function The TURN function is used to switch between menus and for setting values.

Turn to the right > next menu/increase value

Turn to the left > previous menu/decrease value

PRESS function The PRESS function is used to enter the menu.

One press > confirm and next value

Two presses > confirm and previous value







ESC button The ESC button is used to exit a menu.

? button

Press the ? button to bring up help text on the display.

Changing the set value

The hatched field indicates the active value, which can be changed by turning the turn button. Press the press button to confirm the selected choice. Press the ESC button to exit a menu. The following describes a programming sequence.

Handheld terminal TURN/PRESS	Action	
	FIND MENU	Find the desired menu choice in the display by turning the turn button.
	SELECT MENU	Select the desired menu by pressing the press button.
	SEARCH FOR VALUE	Find the value you wish to change by turning the turn button.
	SELECT VALUE	Select the desired value by pressing the press button.
	SET VALUE	Set the desired value by turning the turn button right or left.
	CONFIRM VALUE	Confirm the set value and go to the next parameter.

NB! If the buttons on the handheld terminal are not activated in 30 minutes, the unit automatically logs out to user level.

1.1.2 Operating levels

The menus in the hand terminal are divided into three operating levels:

- User level - free access
- Technician/Installation engineer level - requires password
- Service level - requires password

1.2 Passwords

Login at a higher level also gives access to the underlying levels.


Handheld terminal

Level	Password
User	No password
Technician	1111
Service	1112

It is not possible to change password on the terminal.







2. User mode

2.1 User menu





The user level menu gives access to operating times, temperature setpoint, clock, alarms, software version and IP address.
No password is required for user level.



2.1.1 Fan operation

User menu		
Fan operation		Description
		FAN OPERATION Setting operating state.
Submenu	Submenu	
		Set fan operation <ul style="list-style-type: none"> • SERVICE • constant STOP • LOW speed • HIGH speed • Automatic operation according to weekly program
		SERVICE The unit in in Service stop and can only be started again via this function on the terminal. This prevents the unit being overridden by external systems or accidental start-up and operation during servicing.
		Shows current "weekly program"
		Select type of weekly program <ul style="list-style-type: none"> • Same program all week • Weekday and weekend • Individual daily program
		Set weekly program 4 periods can be entered for each menu display in the selected weekly program. Set speed (columns) <ul style="list-style-type: none"> • STOP • LOW • HIGH Set time <ul style="list-style-type: none"> • Start • Stop HIGH speed has priority in case of time overlap. Number of menu displays/programs <ul style="list-style-type: none"> 1 / Whole week 2 / Weekday and weekend 7 / Daily program



2.1.2 Extended operation

User menu		
Extended operation		Description
		EXTENDED OPERATION Setup of extended operation period.
Submenu	Any comments	
		<p>Extended operation can override the weekly program for an adjusted time period within 7 days.</p> <ul style="list-style-type: none"> • Set starting time: [hh:mm weekday] • Set finishing time: [hh:mm weekday] • Set operating speed (columns) HIGH/LOW • Active: Off / On <p>When the period runs out, operation will automatically continue according to the weekly program.</p>



2.1.3 Temperature

User menu		
Temperature		Description
		TEMPERATURE Setting of the setpoint temperature for the selected regulation type.
Submenu	Any comments	
	*Shown if Temp. setpoint offset is configured and External setpoint is selected	<p>Shows the current temperature and regulation type.</p> <p>Setting the</p> <ul style="list-style-type: none"> • Setpoint temperature • Night-time reduced duty • External offset* • Corrected setpoint*



2.1.4 Time and date

User menu		
Time and date	Description	
	TIME AND DATE Entering time and date.	
Submenu	Any comments	
	Setting the <ul style="list-style-type: none"> • Year • Date and month • Day of the week • Time <p>EXcon control's built-in clock is among other things used by the weekly program.</p>	



2.1.5 Alarm log

User menu		
Alarm log	Description	
	ALARM LOG Shows the latest alarms.	
Submenu	Any comments	
	<p>This shows the time, date and alarm no. of the 4 most recent alarms.</p> <p>A corresponding log of 5-16 most recent alarms is shown on the next menu displays.</p> <p>See alarm list for further information.</p>	

2.1.6 About the control system

User menu		
About the control system	Description	
	ABOUT THE CONTROL SYSTEM Shows the current software version.	
Submenu	Any comments	
	Current software version <ul style="list-style-type: none"> • Control (EXcon Master) • Hand terminal (EXcon Hand terminal) 	

2.1.7 Internet

User menu		
Internet	Description	
	INTERNET Internet settings - TCP/IP communication	
Submenu	Any comments	
	Set IP address. <ul style="list-style-type: none"> • Static: Set network parameters • Dynamic (DHCP): Address is assigned for the closed network. 	

3. Installer level

3.1 Installer menu




The menu at installer level gives access to selections and settings for regulation types and integral functions.

Password









The password for the installer level must be set to allow access to underlying menus.








- Code 1111




Failure to observe instructions marked with a danger symbol may result in personal injury and/or damage to the unit.











3.1.1 Fan operation

Installer menu		
Fan operation		Description
		FAN OPERATION Selection of fan regulation type, setpoints and automatic functions.
Submenu	Any comments	
		Shows current operating values <ul style="list-style-type: none"> Outdoor air [m³/h] / [l/s] Exhaust air [m³/h] / [l/s] Extract air [m³/h] / [l/s] [Pa] [ppm CO₂] [%] Supply air [m³/h] / [l/s] [Pa] [%]
		Adjust setpoint - Low speed <ul style="list-style-type: none"> Extract air [m³/h] / [l/s] [Pa] [ppm CO₂] [%] Supply air [m³/h] / [l/s] [Pa] [%]
		Adjust setpoint - High speed <ul style="list-style-type: none"> Extract air [m³/h] / [l/s] [Pa] [ppm CO₂] [%] Supply air [m³/h] / [l/s] [Pa] [%]
	Shown for regulation modes: <ul style="list-style-type: none"> Constant pressure Extract air slave Supply air slave 	Set air quantity <ul style="list-style-type: none"> Max extract air [m³/h] [l/s]* Max supply air [m³/h] [l/s]** <p>* Not shown for extract air slave ** Not shown for supply air slave</p>
	Shown for regulation modes: <ul style="list-style-type: none"> Constant VOC/CO₂ 	Set min/max airflow <ul style="list-style-type: none"> Min airflow [m³/h] Max airflow [m³/h]
	Shown for regulation modes: <ul style="list-style-type: none"> Fan optimiser slave 	Offset <ul style="list-style-type: none"> Offset extract air [%]
	Shown only if cooling is installed	Set cooler speed <ul style="list-style-type: none"> Forced cooling: On/ Off % increase of fan speed when cooling is active.




Installer menu	
Fan operation	Description
	<p>Select fan regulation form</p> <ul style="list-style-type: none"> • Constant pressure P [Pa] • Constant airflow [m³/h] / [l/s] • Extract air slave [Pa] & [m³/h] [l/s] • Supply air slave [Pa] & [m³/h] [l/s] • Constant VOC/CO₂ [ppm CO₂] • Fan optimiser [m³/h] [l/s] • Fan optimiser slave [%] & [m³/h] [l/s] • Constant motor speed [%]
	<p>Shown for modulated circulating air / VOC/CO₂ intermittent circulating air</p> <p>Set fan regulation</p> <ul style="list-style-type: none"> • Set point for max VOC/CO₂ [ppm] • Setpoint for min. VOC/CO₂ [ppm]* • Setpoint for minimum outdoor air [%] • Recirculation air VOC/CO₂: On/Off <p>* Shown only if VOC/CO₂ intermittent circulating air is selected</p>
	<p>Read-out of pressure transmitter Modbus addresses</p> <ul style="list-style-type: none"> • Extract air = PTH-6202 SwX • Supply air = PTH-6202 SwY
	<p>Shown for regulation modes:</p> <ul style="list-style-type: none"> • Fan Optimiser <p>Override supply air</p> <ul style="list-style-type: none"> • Fire: Yes/No • Cooling: Yes/No • Summer night cooling: Yes/No
	<p>Shown for regulation modes:</p> <ul style="list-style-type: none"> • Fan Optimiser • Fan optimiser slave <p>Override exit air</p> <ul style="list-style-type: none"> • Fire: Yes/No • Cooling: Yes/No • Summer night cooling: Yes/No
	<p>Set fan compensation</p> <ul style="list-style-type: none"> • Outdoor temperature compensation: On/ Off
	<p>Shown only if outdoor temperature compensation is: On</p> <p>Set outside temperature compensation</p> <ul style="list-style-type: none"> • Max setpoint reduction [%] • Outdoor temperature for full compensation [°C] • Outdoor temperature for start of compensation [°C]

Installer menu	
Fan operation	Description
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / ALARMRELAYS</p>  </div>	<p>Set alarm relay function Set function of B-alarm relay to, for example, operation of extra fan.</p> <p>B-Alarm:</p> <ul style="list-style-type: none"> • B Alarm • Low speed • High speed • Summer night cooling <p>A-Alarm:</p> <ul style="list-style-type: none"> • A-Alarm • A + B alarm
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / EXTERNAL HIGH</p> <p>Set run-on for external high input:</p> <p>Run-on time: 0 Min.</p> </div>	<p>Set run-on/operating time for digital input External high</p> <p>E.g. from a connected PIR sensor or an extended operation impulse switch.</p> <ul style="list-style-type: none"> • Run-on [min]



3.1.2 Temperature

Installer menu		
Temperature		Description
		TEMPERATURE Setting of temperature regulation type, cooling and automatic functions.
Submenu	Any comments	
	Shown if Outdoor air temperature (external sensor) is configured	External outdoor temperature sensor <ul style="list-style-type: none"> • Switch on/off external outdoor temperature sensor
		Shows current operating temperatures <ul style="list-style-type: none"> • Outdoor temperature [°C] • Exhaust air [°C] if installed • Extract air [°C] if installed • Supply air [°C] • Current regulation form <p> Shown only when room operation is installed.</p> <p>Symbols which are only shown when Summer/Winter changeover is activated:</p> <ul style="list-style-type: none">  Shown only when the unit is in summer operation.  Shown only when the unit is in winter operation.
		Set temperature setpoint <ul style="list-style-type: none"> • Max. supply air temperature [°C] • Temperature setpoint [°C] • Min. supply air temperature [°C] <p>Max. and min. are not shown when constant supply air temperature is selected.</p> <ul style="list-style-type: none"> • Calibrate room temperature measurement = Setting of sensor offset on room sensor.
	Shown only if cooling is installed	Minimum input air for cooling requirement <ul style="list-style-type: none"> • Min. supply air temperature [°C]
		Set temperature regulation form <ul style="list-style-type: none"> • Constant supply air • Constant extract air • Constant room • Constant supply/extract air difference
		Summer/winter compensation <ul style="list-style-type: none"> • On/Off Summer/winter compensation






Installer menu		
Temperature		Description
	Shown only if summer/winter compensation is: On	Setting compensation of temperature setpoint <ul style="list-style-type: none"> • Summer temperature difference [°C] • Summer start [°C] • Summer maximum [°C]
	Shown only if summer/winter compensation is: On	Winter compensation of temperature setpoint <ul style="list-style-type: none"> • Winter temperature difference [°C] • Winter start [°C] • Winter maximum [°C]
	Shown only if circulation air is installed and temperature regulation is set to: Constant room temperature	Set recirculation air function <ul style="list-style-type: none"> • Recirculation function: On/ Off • Recirculation stop temperature [°C] • Recirculation start temperature [°C]
	Shown only if VOC/CO₂ intermittent circulating air is selected	Fan speed - VOC/CO₂ intermittent recirculation air <ul style="list-style-type: none"> • Alter fan speed to: Low speed/High speed Set fan speed when the system is running minimum night/night heating.
		Summer night cooling <ul style="list-style-type: none"> • Status: On/ Off • Start time for summer night cooling • Stop time for summer night cooling
	Shown if summer night cooling is: On	Set summer night cooling <ul style="list-style-type: none"> • Stop outdoor air temperature [°C] • Start room temperature [°C] • Stop room temperature [°C] • Min supply air temperature [°C]
	Shown if summer night cooling is: On	Summer night cooling, set fan setpoint <ul style="list-style-type: none"> • Supply air [%] • Extract air [%]
	Shown if cooling is installed	Cold recovery <ul style="list-style-type: none"> • On/Off cold recovery
	Shown for: <ul style="list-style-type: none"> • Water cooling • External DX 	Set cooling stop on active cooling at low outdoor temperature, so free cooling can be used <ul style="list-style-type: none"> • Cooling stop [°C]
	Shown for: <ul style="list-style-type: none"> • DX cooling 	Minimum outdoor temperature cooling stop <ul style="list-style-type: none"> • Outdoor air temp. 1, stop [°C] (stop cooling step 1) • Outdoor air temp. 2, stop [°C] (stop cooling step 2) • Outdoor air temp. 3, stop [°C] (stop cooling step 3) • Outdoor air temp. 4, stop [°C] (stop cooling step 4)

Installer menu	
Temperature	Description
	<p>Shown at following temperature regulations:</p> <ul style="list-style-type: none"> • Constant extract air temperature • Constant room temperature
	<p>Shown if change is:</p> <p>Outdoor air temperature</p> <ul style="list-style-type: none"> • Summer for higher temperature [°C] • Winter for lower temperature [°C] • Not changed if the temperature is within the summer/winter limits.
	<p>Shown if change is:</p> <p>Calendar</p> <ul style="list-style-type: none"> • Changeover to summer operation on this date • Changeover to winter operation on this date

3.1.3 Initial adjustment




Installer menu	
Initial adjustment	Description
	<p>INITIAL SETTINGS</p> <p>Lock fan speeds while making manual adjustments to the VAV damper in the ventilation ducts.</p>
<p>Submenu</p> 	<p>Any comments</p> <p>Setting of time during which fan speeds are locked at the speed level set in the FIRE menu.</p> <ul style="list-style-type: none"> • Set time: hh:mm <p>The fans are locked at their current speed if the time is set to any value other than 00:00.</p> <p>The time automatically counts down.</p> <p>The lock is deactivated by setting the time to 00:00 and waiting max. 60 s</p>

3.1.4 Fire



Installer menu		
Fire		Description
		FIRE Setting of fan speed in case of fire alarm, and temperature limit for internal fire alarm in the machine.
Submenu	Any comments	
		Set fire ventilation When the fire alarm is activated, the fan is forced to operate at the set speed. <ul style="list-style-type: none"> • Extract air fan [%] • Supply air fan [%]
		Set the temperature limits for internal fire alarm in the unit <ul style="list-style-type: none"> • Temperature in extract air [°C] • Temperature in supply air [°C]
	Shown only if a digital input and output are configured for the fire damper test	Set testing of fire damper <ul style="list-style-type: none"> • Setting of fire damper test • Time of fire damper test • Result of last test. • Manual test • Residual time for this test.
	Shown only if a digital input and output are configured for the fire damper test	Option for fire damper at shutdown Select whether the fire damper is to open or close in the case of unit shutdown.

NB: The selected fans mode must meet regulatory standards.




3.1.5 Communication

Installer menu		
Communication	Description	
	COMMUNICATION Modbus/RTU settings	
Submenu	Any comments	
	Modbus settings Settings for remote communication on Modbus RS485 connection. <ul style="list-style-type: none"> • Modbus address [1 - 240] • Baud rate (9600, 19200, 38400) • Parity[None, Equal, Unequal] • Stopbit [1, 2] • Startbit [1, 2] 	
	Shown only if LON is installed	Show LON information <ul style="list-style-type: none"> • Neuron ID • Program ID • External interface file • Resource file set










3.1.6 Language











Installer menu		
Language	Description	
	SROG Select language in handheld terminal	
Submenu	Any comments	
	Set language Select language: <ul style="list-style-type: none"> • Swedish • Norwegian • Danish • English • German • French • Russian • Dutch • Finnish <p>Language will change to the selected option on exiting the menu.</p>	







3.1.7 Factory setting

Installer menu		
Factory setting		Description
		<p>DEFAULT SETTINGS Recreate default settings in control system.</p>
<p>Submenu</p> 	<p>Any comments</p>	<p>Confirm retrieval of default settings</p> <p>ESC: aborts OK: Continues</p>
		<p>Acknowledgement of correct re-entry of default settings.</p>

3.1.8 Store functions

Installer menu		
Store functions		Description
		<p>SHOP FUNCTIONS Select on and off settings for energy saving functions.</p> <p>This menu is only available if, under EXcon modules > configure > SettingsShop functions is crossed off.</p>
Submenu	Submenu	
		Setting of functions in fan
		<p>Set speed change for fans</p> <ul style="list-style-type: none"> • None • Change Low Low > High • Change High > Low
		<p>Set heating 2</p> <p>Choose whether activation of Heat2 is to override fan speed.</p> <ul style="list-style-type: none"> • Set fan speed change in case of active Heat2.
		Set functions in recirculation damper
		<p>Set blocking of Heat2 with recirculation air</p> <ul style="list-style-type: none"> • Mark to activate blocking <p>Heat 2 is blocked when the unit runs with air recirculation.</p>
		<p>Set heating with recirculation air</p> <ul style="list-style-type: none"> • Mark to activate the function • Set heating time [Sec] • Read off current start-up time [s] • Set outdoor temperature for activation [°C] <p>When the function is activated, the unit will operate with recirculation during the early morning heating of the shop if the outdoor temperature is above the set value.</p>
		Set function for Heat 1
		<p>Set min return water limits</p> <ul style="list-style-type: none"> • Mark to activate the function • Set min. return temperature in Heat 1 [°C] • Set time delay for heat 1 [Sec] • Read off current blocking time [s]

Installer menu		
Store functions		Description
Shown only if reg. type Standard is selected.		Select Heat 1 regulation type Select Standard if Heat1 is to be regulated as a single heating surface.
Shown only if reg. type Splitter is selected.		Select Heat 1 regulation type Select Splitter if Heat1 is to be regulated as 2 heating surfaces connected in sequence = Heat1 and Heat12 <ul style="list-style-type: none"> • Set exit signal Heat 12 [0-10V/2-10V] • Read off current exit signal for Heat 12 [V]
Shown only if reg. type Splitter is selected.		Set reg. parameters for exit Heat 12 <ul style="list-style-type: none"> • Mark to activate the function • Set delay for condenser [s] • Read off current condenser delay [s]
Shown only if reg. type Splitter is selected.		Set reg. parameters for exit Heat 12 <ul style="list-style-type: none"> • Set min active time for Heat 12 • Read off current active time for Heat 12 • Mark for activation of rise/fall time • Set min rise/fall time [Sec]
Shown only if reg. type Splitter is selected.		Set reg. parameters for exit Heat 12 <ul style="list-style-type: none"> • Mark to activate hysteresis Heat 1 • Set hysteresis for relay Heat 1 [%]
Shown only if reg. type Splitter is selected.		Set reg. parameters for exit Heat 1 <ul style="list-style-type: none"> • Mark to deactivate Heat 1
Shown only if reg. type Copy is selected.		Select Heat 1 regulation type Select Copy if Heat 1 is to be regulated as 2 heat surfaces connected in parallel.
		Set limits for Heat 2 In many cases Heat2 is an electrically heated surface. To save energy from this heat source, the control system may be set to automatically reduce use of this heat source, depending on the deviation from room temperature or depending on outdoor temperature.
		Set limits for Heat 2 <ul style="list-style-type: none"> • None - no limits for Heat 2
Shown only for Room temperature limitation		Room temperature limits <ul style="list-style-type: none"> • Set temperature difference (setpoint/current) [°C] • Connection degree per step [%] • Read of Temperature (setpoint/current) [°C]

Installer menu		
Store functions		Description
Shown only in case of "outdoor temperature" limits		Outdoor temperature limits <ul style="list-style-type: none"> • Set connection level [°C] • Read off current outdoor temperature [°C]
		Delayed start-up Heat 2 <ul style="list-style-type: none"> • Mark to activate the function • Set delayed start Heat 2 [Sec.] • Read off current time in delayed start [Sec]
		Set cooling limits
		Limit cooling in case of high room temperature <p>The function is set to block connection of cooling even though there is an active cooling requirement.</p> <ul style="list-style-type: none"> • Mark to activate the function • Set setpoint for stop of cooling [°C] <p>If the current room temperature exceeds this setpoint, cooling will be blocked.</p>
		Blocking of cooling <p>This function is used to limit cooling with fresh air.</p> <ul style="list-style-type: none"> • Mark to activate the function • Set free cooling stop setpoint [°C]
		Cold recovery <ul style="list-style-type: none"> • Mark to activate the function <p>The function is meant to ensure that when there is a cooling requirement and the outdoor temperature is +1°C > room temperature, the unit damper will be diverted to minimum fresh air to save cooling energy.</p>

4. Service level

4.1 Service menu




The service level menu gives access to the operating values, settings and forced operation of the unit's components.

Password









The password must be set to allow access to underlying menus. The password gives automatic access to installer level.









- Code 1112



Failure to observe instructions marked with a danger symbol may result in personal injury and/or damage to the unit.








4.1.1 Fan

Service menu	
Fan	Description
	<p>FAN Show current operating status. Set functions and forced fan control.</p>
<p>Submenu</p>	<p>Any comments</p>
	<p>Set fan operation</p> <ul style="list-style-type: none"> • SERVICE • Manual STOP • Constant LOW speed • Constant HIGH speed • Automatic operation according to weekly program <p>NB! When setting SERVICE, the unit cannot be started from the WEB user interface, but only from the hand-held terminal.</p>
	<p>Supply air fan operating status</p> <ul style="list-style-type: none"> • Current setpoint [%] • Specific Fan Power SFP [J/m3] • Current power consumption [W] • Current rpm [RPM] • Current ventilation [m3/h] [l/s] [Pa] • Current k-factor for calculating airflow <p>Symbol  is shown when an alarm from the frequency converter is triggered.</p>
	<p>Forced control of supply air fan and setting of K factor.</p> <p>Forced operation is only possible once the unit has started.</p> <ul style="list-style-type: none"> • Set the forced control setpoint [%] • Setting of remaining time until forced control expires [hh:mm:ss] • Activate forced control: On/Off • Current rpm [RPM] • Current ventilation [m3/h] [l/s] [Pa] • Setting of k-factor <p>Symbol  is shown when an alarm from the frequency converter is triggered.</p>
	<p>Extract air fan operating status</p> <ul style="list-style-type: none"> • Current setpoint [%] • Specific Fan Power SFP [J/m3] • Current power consumption [W] • Current rpm [RPM] • Current ventilation [m3/h] [l/s] [Pa] • Current k-factor for calculating airflow <p>Symbol  is shown when an alarm from the frequency converter is triggered.</p>

Service menu	
Fan	Description
	<p>Forced control of supply air fan and setting K factor.</p> <p>Forced operation is only possible once the unit has started.</p> <ul style="list-style-type: none"> • Set the forced control setpoint [%] • Setting of remaining time until forced control expires [hh:mm:ss] • Activate forced control: On/Off • Current rpm [RPM] • Current ventilation [m³/h] [l/s] [Pa] • Setting of k-factor <p>Symbol  is shown when an alarm from the frequency converter is triggered.</p>
	<p>Setting of delayed fan start</p> <ul style="list-style-type: none"> • Supply air fan delay [sec] <p>Starts x secs after extract air fan</p> <ul style="list-style-type: none"> • Extract air fan delay [sec] <p>Starts y sec. after start of damper opening.</p>
	<p>Set temperature regulation</p> <ul style="list-style-type: none"> • P-band cooling [°C] • P-band heating [°C] • Shows current temperature [°C] • Correction value [°C]
	<p>Set regulation parameters for input</p> <ul style="list-style-type: none"> • I-time airflow [sec] • I-time cooling [sec] • I-time heat recovery [sec] • I-time heating 1 [sec] • I-time combi[sec]
	<p>Set regulation parameters for input</p> <ul style="list-style-type: none"> • I-time heating 2 [sec] • I-time heat pump [sec]
	<p>Set temperature regulation for exit air</p> <ul style="list-style-type: none"> • P-band cooling [°C] • P-band heating [°C] • Shows current temperature [°C] • Correction value [°C]
	<p>Set regulation parameters for exit air</p> <ul style="list-style-type: none"> • I-time airflow [sec] • I-time cooling [sec] • I-time heat recovery [sec] • I-time heating 1 [sec] • I-time combi [sec]







Service menu	
Fan	Description
08:32 / EXTRACT AIR I-time heating 2: 600 Sec. I-time heat pump: 600 Sec.	Set regulation parameters for exit air <ul style="list-style-type: none"> • I-time heating 2 [sec] • I-time heat pump [sec]
08:32 / EXHAUST AIR Calibrate temperature measurement Current temperature: 15.0 °C Correction factor: 0.0 °C	Calibrate temperature measurement for exhaust air (sensor correction/offset) <ul style="list-style-type: none"> • Shows current temperature [°C] • Correction value [°C]
08:32 / OUTDOOR AIR Temperature sensor correction Current temperature: 0.0 °C Correction factor: 0.0 °C	Calibrate temperature measurement for outdoor air (sensor correction/offset) <ul style="list-style-type: none"> • Shows current temperature [°C] • Correction value [°C]



4.1.2 Filter







Service menu		
Filter		Description
		FILTER Show current pressure. Setting of filter alarms.
Submenu	Any comments	
		<p>Set outdoor air filter alarm limit</p> <ul style="list-style-type: none"> • Setting of alarm limit [Pa] [%] • Current alarm limit [Pa] * • Current filter pressure [Pa] <p>Symbol  is shown when a filter alarm is triggered.</p> <p>* Shown only in the event of a dynamic filter alarm</p>
		<p>Set exit air filter alarm limit</p> <ul style="list-style-type: none"> • Setting of alarm limit [Pa] [%] • Current alarm limit [Pa] * • Current filter pressure [Pa] <p>Symbol  is shown when a filter alarm is triggered.</p> <p>* Shown only in the event of a dynamic filter alarm</p>
		<p>Set filter alarm type and measurement of filter pressure reference</p> <ul style="list-style-type: none"> • Set alarm type: Static/Dynamic • Start filter measurement: Yes/No • Show status of filter measurement <ul style="list-style-type: none"> • Not measured • Filter measurement in progress • Filter measurement completed <p>Static: The alarm limit is fixed and set in Pa</p> <p>Dynamic: The Alarm limit depends on the current air quantity and is set in % deviation relative to measured filter pressure reference.</p> <p>Filter measurement: When dynamic alarm type is selected, a filter reference pressure must be measured on a clean filter.</p> <p>If the filter is changed during servicing, the filter measurement must be repeated. When Yes is selected, the unit automatically measures the filter pressure as a function of flow, and the sequence lasts about 10 min. Both filters are measured at the same time.</p>
		<p>Start filter measurement Confirm to start filter measurement, press Esc to abort.</p>





Service menu	
Filter	Description
<div style="border: 1px solid black; padding: 5px;"><p>08:32 / FILTER ALARM</p><p>Alarm type: Dynamic</p><p>Start filter measurement: No</p><p>Status:Filter measurement complete</p><p>Supply air fan: 23.1 %</p></div>	<p>Filter measurement complete</p> <p>Acknowledgement that filter measurement is in progress/is complete.</p>




4.1.3 Heating

Service menu		
Heating		Description
		<p>HEATING Show current operating status. Set functions and forced fan control of heating coils.</p>
Submenu	Any comments	
		<p>Show current operating status. Set temperature for heating coil 1</p> <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current heating [%] • Set max supply air temp. [°C] * • Current supply air temperature [°C] • Set min supply air temp. [°C] * <p>Symbol  is shown when an alarm from the heat interface is triggered.</p> <p>* Not shown for temperature regulation: Constant supply air</p>
		<p>Show current operating status. Set temperature for heating coil 2</p> <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current heating [%] • Set max supply air temp. [°C] * • Current supply air temperature [°C] • Set min supply air temp. [°C] * <p>Symbol  is shown when an alarm from the heat interface is triggered.</p> <p>* Not shown for temperature regulation: Constant supply air</p>
Electric heating coil		
	Shown for the electric heating coil 1	<p>Show current operating status. Set regulation for current type of electric heating coil 1</p> <ul style="list-style-type: none"> • Current heating [%] • Set regulation form: <ul style="list-style-type: none"> • 0-10 V • 1 step • 2 step • 3 step • 4 step • 5 step • 7-step binary • Overheating: Low/High • Current signal at heat output [V] • Current status Heating relay 1: Open/closed • Current status Heating relay 2: Open/closed








Service menu		
Heating		Description
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / FORCED CONTROL HEATING 1:</p> <p>Heating 1: 0.0 %</p> <p>Timeout: 00:00:00</p> <p>Forced control 1: Off</p> <p>Heating output 1: 0.0 V</p> <p>Heating relay 1: Open</p> <p>Heating relay 2: Open</p> </div>	Shown for the electric heating coil 1	<p>Forced control of electric heating coil</p> <p>Forced operation is only possible once the unit has started.</p> <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/Off • Current signal at heating output [V] • Current status Heating relay 1: Open/closed • Current status Heating relay 2: Open/closed
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / MIN. AIRFLOW, 0% HEATING 1</p>  </div>	Shown for the electric heating coil 1	<p>Set min airflow for partially connected electric heating coil 1</p> <ul style="list-style-type: none"> • Set supply airflow [m3/h] [l/s] <p>Reduced is displayed if the heating output is reduced due to low airflow.</p>
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / MIN. AIRFL., 100% HEATING 1</p>  </div>	Shown for the electric heating coil 1	<p>Set min airflow for 100% connected electric heating coil 1</p> <ul style="list-style-type: none"> • Set supply airflow [m3/h] [l/s] <p>Reduced is displayed if the heating output is reduced due to low airflow.</p>
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / ELECTRIC COIL 2</p> <p>Heating 2: 0.0 %</p> <p>Regulation 2: 0-10V</p> <p>Overheating 2: Low</p> <p>Heating output 2: 0.0 V</p> <p>Heating relay 21: Open</p> <p>Heating relay 22: Open</p> </div>	Shown for the electric heating coil 2	<p>Show current operating status. Set regulation for current type of electric heating coil 2.</p> <ul style="list-style-type: none"> • Current heating [%] • Set regulation form: <ul style="list-style-type: none"> • 0-10 V • 1 step • 2 step • 3 step • 4 step • 5 step • 7-step binary • Overheating: Low/High • Current signal at heating output [V] • Current status Heating relay 21: Open/closed • Current status Heating relay 22: Open/closed
<div style="border: 1px solid black; padding: 5px;"> <p>08:32 / ELECTRIC COIL 2</p> <p>Heating relay 21: Open</p> <p>Heating relay 22: Open</p> <p>Heating relay 23: Open</p> <p>Heating relay 24: Open</p> <p>Heating relay 25: Open</p> <p>Heating relay 26: Open</p> </div>	Shown for the electric heating coil 2	<p>Current status electric heating coil 2</p> <ul style="list-style-type: none"> • Current status Heating relay 21: Open/closed • Current status Heating relay 22: Open/closed • Current status Heating relay 23: Open/closed • Current status Heating relay 24: Open/closed • Current status Heating relay 25: Open/closed • Current status Heating relay 26: Open/closed




Service menu		
Heating		Description
	Shown for the electric heating coil 2	Forced control of electric heating coil 2 Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Current signal at heating output [V] • Current status Heating relay 21: Open/closed • Current status Heating relay 22: Open/closed
	Shown for the electric heating coil 2	Set min airflow for partially connected electric heating coil 2 <ul style="list-style-type: none"> • Set supply airflow [m3/h] [l/s] Reduced is displayed if the heating output is reduced due to low airflow.
	Shown for the electric heating coil 2	Set min airflow for 100% connected electric heating coil 2 <ul style="list-style-type: none"> • Set supply airflow [m3/h] [l/s]
	Shown for electric heating coil	Set after cooling time of electric heating coil <ul style="list-style-type: none"> • Set time [sec] In case of shutdown, the supply air fan continues operation during the aftercooling time.
Water heating coil		
	Shown for the water heating coil 1	Show current operating status. Set frost alarm on water heating coil 1 <ul style="list-style-type: none"> • Current heating 1 [%] • Current supply air temperature [°C] • Current water temperature 1 [°C] • Frost alarm 1 [°C] • Current status Heat relay 1: Open/closed • Set motor valve's regulation area [2-10V = VEX4000 standard]
	Shown at Belimo Modbus valve	Heating coil 1, Modbus <ul style="list-style-type: none"> • Current valve setting [%] • Absolute position [Feedback] • Test run: Yes/No • Communication: Active / Inactive


Service menu		
Heating		Description
08:32 / FORCED CONTROL HEATING1 Heating1: 0.0 % Supply air temperature: 20.0 °C Timeout: 00:00:00 Forced control: Off Heating output 1: 0.0 V Heating relay 1: Closed	Shown for the water heating coil 1	Forced control of water heating coil 1 Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> Set forced operation setpoint [%] Current supply air temperature [°C] Set remaining time until forced operation terminates [hh:mm:ss] Activate forced operation: On/ Off Current signal at heating output [V] Current status Heating relay 1: Open/closed
08:32 / PUMP1 OPERATION 	Shown for the water heating coil 1	Set pump operation 1 Pump operation can be set to: <ul style="list-style-type: none"> Constant operation Auto Outdoor air temperature Heating requirement Start appears when pump is in operation.
08:32 / PUMP1 START TEMPERATURE 	Shown at Water heating coil 1 and if outdoor temperature is selected	Set pump 1 start temperature <ul style="list-style-type: none"> The pump starts when the outdoor temperature is lower than the set value. [°C] Start appears when pump is in operation.
08:32 / PUMP1 START HEATING% 	Shown at Water heating coil 1 and if outdoor temperature is selected	Set pump 1 start temperature <ul style="list-style-type: none"> The pump starts when the outdoor temperature is lower than the set value. [%] Start appears when pump is in operation.
08:32 / FROST PROTECTION1 Frost protection1: 5.0 °C Frost alarm1: 2.0 °C Frost P-band1: 5.0 °C Start-up heating1: 0.0 % Standby heating1: 25.0 °C Water temperature1: 0.0 °C	Shown for the water heating coil 1	Setting of frost protection in hot water interface 1 <ul style="list-style-type: none"> Set temperature for full frost protection [°C] Set temperature for frost alarm [°C] Set frost protection P-band [°C] Set heat boost upon start-up [%] Set hot water interface temperature to standby [°C] Current water temperature [°C]
08:32 / HEATING COIL 2 Heating2: 10.0 V / 100.0 % Supply air temperature: 0.0 °C Water temperature 2: 0.0 °C Frost alarm2: 2.0 °C Heating relay 21: Closed Motor valve: 0-10V	Shown for the water heating coil 2	Show current operating status. Set frost alarm on water heating coil 2 <ul style="list-style-type: none"> Current heat 2 [%] Current input air temperature [°C] Current water temperature 2 [°C] Frost alarm 2 [°C] Current status Heat relay 21: Open/closed Set motor valve's regulation area [2-10V = VEX4000 standard]
08:32 / HEATING COIL 2  Current valve position 0.0 % Absolute position: 0 ° Test run: No Not active	Shown at Belimo Modbus valve	Heating coil 2, Modbus <ul style="list-style-type: none"> Current valve setting [%] Absolute position [Feedback] Test run: Yes/No Communication: Active / Inactive

Service menu		
Heating		Description
08:32 / FORCED CONTROL HEATING 2 Heating 2: 0.0 % Supply air temperature: 0.0 °C Timeout: 00:00:00 Forced control 2: Off Heating output 2: 10.0 V Heating relay 21: Closed	Shown for the water heating coil 2	Forced control of water heating coil 2 Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Current input air temperature [°C] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Current signal at heat output [V] • Current status Heat relay 21: Open/closed
08:32 / PUMP 2 OPERATION 	Shown for the water heating coil 2	Set pump operation Pump operation can be set to: <ul style="list-style-type: none"> • Constant operation • Auto • Outdoor air temperature • Heating requirement Start appears when pump is in operation.
08:32 / PUMP 2 START TEMPERATURE 	Shown at Water heating coil 2 and if outdoor temperature is selected	Set pump 2 start temperature <ul style="list-style-type: none"> • The pump starts when the outdoor temperature is lower than the set value. [°C] Start appears when pump is in operation.
08:32 / PUMP 2 START HEAT DEMAND 	Shown at Water heating coil 2 and if outdoor temperature is selected	Set pump 2 start temperature <ul style="list-style-type: none"> • The pump starts when the outdoor temperature is lower than the set value. [%] Start appears when pump is in operation.
08:32 / FROST PROTECTION 2 Frost protection 2: 5.0 °C Frost alarm 2: 2.0 °C Frost P-band 2: 5.0 °C Start-up heating 2: 50.0 % Standby heating 2: 25.0 °C Water temperature 2: 0.0 °C	Shown for the water heating coil 2	Setting of frost protection in water heating coil 2 <ul style="list-style-type: none"> • Set temperature for full frost protection [°C] • Set temperature for frost alarm [°C] • Set frost protection P-band [°C] • Set heat boost upon start-up [%] • Set Water heating coil temperature to standby [°C] • Current water temperature [°C]








4.1.4 Heating recovery



Service menu		
Heating recovery		Description
		HEATING RECOVERY Show current operating status. Set functions and forced fan control of heat exchanger.
Submenu	Submenu/Any comments	
Crossflow heat exchanger		
		Shows current status of crossflow heat exchanger <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current exhaust air temperature [°C] • Current recovery signal [%] • Current extract air temperature [°C] • Current supply air temperature [°C] • Current heating recovery [%]
		Forced control of crossflow heat exchanger Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Set forced operation setpoint [%] • Current extract air temperature [°C] • Current supply air temperature [°C] • Current heat recovery [%]
		Efficiency crossflow heat exchanger <ul style="list-style-type: none"> • Current efficiency [%] • Correction factor [%] • Alarm in case of low efficiency: Yes/No • Alarm level [%]
	Shown at Belimo Modbus damper	Bypass damper, Modbus <ul style="list-style-type: none"> • Current damper setting [%] • Absolute position [Feedback] • Test run: Yes/No • Communication: Active / Inactive
	Shown for temperature-controlled ice protection	Set ice-protection of crossflow heat exchanger <ul style="list-style-type: none"> • Set ice protection temperature [°C] • Set ice protection P band. [°C] • Shows current exhaust air temperature [°C] • Ice protection in progress: Yes/No
	Shown for temperature-controlled ice protection	Show status of crossflow heat exchanger <ul style="list-style-type: none"> • Shows current exhaust air temperature [°C] • Protection in progress: Yes/No








Service menu		
Heating recovery		Description
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DE-ICING 1 De-icing type: Static Start measurement: No De-icing time: 300 s Remaining de-icing time: 0 s Status: Not measured </div>	Shown for temperature-controlled ice protection	Settings for pressure-controlled de-icing, time <ul style="list-style-type: none"> De-icing type: Static/Dynamic Start measurements: Yes/No De-icing time [s] Remaining de-icing time [s] Measurement status
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DE-ICING 2 Crossfl.heat exchanger pressure: 0 Pa De-icing pressure, static: 30 Pa De-icing pressure, dynamic: 45 % De-icing, current: 30 Pa </div>	Shown for temperature-controlled ice protection	Settings for pressure-controlled de-icing, pressure <ul style="list-style-type: none"> Current crossflow heat exchanger pressure [Pa] De-icing pressure, static [Pa] De-icing pressure, dynamic [Pa] De-icing pressure, current [Pa]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / HEAT RECOVERY Gain factor: 100 </div>		Gain factor <ul style="list-style-type: none"> Set gain factor
Rotary heat exchanger		
<div style="border: 1px solid black; padding: 5px;"> 08:32 / ROTARY HEAT EXCHANGER  0.0 °C 0.0 °C Motor: 0.0 % 0.0 °C 0.0 °C </div>		Shows current status of rotary heat exchanger <ul style="list-style-type: none"> Current outdoor temperature [°C] Current exhaust air temperature [°C] Current recovery signal [%] Current extract air temperature [°C] Current supply air temperature [°C]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / FORCED CTRL. EXCHANGER  Timeout: 00:00:00 Forced control: Off Motor: 0.0 % 25.0 °C 20.0 °C </div>		Forced control of rotary heat exchanger Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> Setting of remaining time until forced control expires: [hh:mm:ss] Activate forced control: On/ Off Set forced operation setpoint for motor [%] Current extract air temperature [°C] Current supply air temperature [°C]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / ROTARY HEAT EXCHANGER  Correction fac. 0.0 % Alarm type: B Alarm at low η: <input checked="" type="checkbox"/> Alarm level η: 70.0 % η: 0 % </div>		Efficiency <ul style="list-style-type: none"> Correction factor [%] Alarm type: A or B Alarm in case of low efficiency: Select/deselect Alarm level [%] Current efficiency [%]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / ROTOR PRESS. DIFF. Measure pressure difference <input type="checkbox"/> Status: Measured Rotor pressure: 0 Pa </div>	Only relevant if pressure inlet: Rot. heat exchanger (outdoor/supply air) is configured	Measure pressure reference <ul style="list-style-type: none"> Measure pressure reference: Select/deselect Measurement status Current pressure over rotor* [Pa] *Pressure over the rotor's supply air string
<div style="border: 1px solid black; padding: 5px;"> 08:32 / ROTOR PRESS. DIFF. Measure pressure difference, de-icing <input type="checkbox"/> Status: Not measured Current pressure, de-icing: 0 Pa Calculated pressure limit, de-icing: 30 Pa </div>	Only relevant if pressure inlet: Rot. heat exchanger, de-icing (exhaust air/extract air) is configured	Dynamic de-icing <ul style="list-style-type: none"> Measure pressure reference, de-icing: Select/deselect Measurement status: Not measured/measured Current pressure over rotor [Pa] Estimate pressure limit, de-icing* [Pa] *Pressure over the rotor's extract air string

Service menu		
Heating recovery		Description
<div style="border: 1px solid black; padding: 5px;"> 08:32 / RHX2MCONTROL Current recovery: 0% Control type: Motor rpm: 0 RPM Motor power: 0 mA Holding torque: 0.0% Software version: 0.00 </div>	Shown only in case of RHX2M (Rotor control)	Show current RHX2M operating status. <ul style="list-style-type: none"> • Current recovery [%] • Current control type: <ul style="list-style-type: none"> • RH2M-1212/1412/1612 • Motor revs [RPM] • Motor power [mA] • Holding torque [%] • Software version in Master
<div style="border: 1px solid black; padding: 5px;"> 08:32 / ROTARY HEAT EXCHANGER  0 m³/h </div>	Only relevant if a PTH sensor and pressure inlet have been mounted Rot. heat exchanger (outdoor/ supply air) is configured	Airflow rotating heat exchanger <ul style="list-style-type: none"> • Shows current air quantity in input air string through heat exchanger [m3/h]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / HEAT RECOVERY Rotor de-icing: <input type="checkbox"/> Pressure, start of de-icing: 50.0 % Pressure, current: 0 Pa </div>	Only relevant if a PTH sensor and pressure inlet have been mounted Rot. heat exchanger, de-icing (exhaust air/extract air) is configured	De-icing rotary heat exchanger <ul style="list-style-type: none"> • Pressure, start of de-icing Select/deselect • Pressure, start of de-icing [%] • Current pressure over rotor* [Pa] *Pressure over the rotor's extract air string
<div style="border: 1px solid black; padding: 5px;"> 08:32 / HEAT RECOVERY Gain factor: 100 </div>		Gain factor <ul style="list-style-type: none"> • Set gain factor

4.1.5 Cooling









Service menu		
Cooling		Description
		COOLING Shows current operating status. Set functions and forced fan control of cooling coils.
Submenu	Any comments	
DX Cooling		
		Shows current status of cooling <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current cooling [%] • Current supply air temperature [°C]
		Forced control of cooling coil Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Current supply air temperature [°C] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Current status Cooling relay 1: Open/closed • Set motor valve's regulation area [2-10V = VEX4000 standard]
		Set regulation for current type DX cooling. <ul style="list-style-type: none"> • Set regulation form: <ul style="list-style-type: none"> • 1 step • 2 step • 1. Step modulating: Yes/No (Yes = VEX4000 standard) • Current cooling error: Yes / No • Current signal at cooling output [V] • Set min. airflow for cooling [m3/h] • Set condenser aftercooling [s]
		Shows current status of cooling relay <ul style="list-style-type: none"> • Current status Cooling relay 1: Open/closed • Current status Cooling relay 2: Open/closed • Current status Cooling relay 3: Open/closed • Current status Cooling relay 4: Open/closed
		Shows current status of cooling circuit <ul style="list-style-type: none"> • Current status Low pressure circuit 1 [Bar] • Current status High pressure circuit 1 [Bar] • Current status Low pressure circuit 2 [Bar] • Current status High pressure circuit 2 [Bar]
		Shows current status of pressure alarms <ul style="list-style-type: none"> • Current status Low pressure alarm 1 [Bar] • Current status High pressure alarm 1 [Bar] • Current status Low pressure alarm 2 [Bar] • Current status High pressure alarm 2 [Bar]









Service menu		
Cooling		Description
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DX COOLING 5 Cooling error comp. 1: No Cooling error comp. 2: No Cooling error comp. 3: No Cooling error comp. 4: No </div>		Shows current status of cooling compressors <ul style="list-style-type: none"> • Current cooling errors compressor 1: Yes/No • Current cooling errors compressor 2: Yes/No • Current cooling errors compressor 3: Yes/No • Current cooling errors compressor 4: Yes/No
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DX COOLING 6 Min. cooling time: 0 Sec. Cooling time relay 1: 0 Sec. Cooling time relay 2: 0 Sec. Cooling time relay 3: 0 Sec. Cooling time relay 4: 0 Sec. </div>		Settings for connection times on cooling relays <ul style="list-style-type: none"> • Set min. cooling time [sec] • Current cooling time relay 1 [sec] • Current cooling time relay 2 [sec] • Current cooling time relay 3 [sec] • Current cooling time relay 4 [sec]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DX COOLING 7 Max. restart/hour: 10/h Restarting relay 1: 0/h Restarting relay 2: 0/h Restarting relay 3: 0/h Restarting relay 4: 0/h </div>		Settings for restart times on cooling relays <ul style="list-style-type: none"> • Set max number restarts per hour • Current number restarts relay 1 • Current number restarts relay 2 • Current number restarts relay 3 • Current number restarts relay 4
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DX COOLING 8 Min. stop time: 600Sec. Stop time, relay 1: 0 Sec. Stop time, relay 2: 0 Sec. Stop time, relay 3: 0 Sec. Stop time, relay 4: 0 Sec. </div>		Settings for stop times on cooling relays <ul style="list-style-type: none"> • Set min stop time [sec] • Current stop time relay 1 [sec] • Current stop time relay 2 [sec] • Current stop time relay 3 [sec] • Current stop time relay 4 [sec]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / DX COOLING 9 Compressor relay 1 blocked: No Compressor relay 2 blocked: No Compressor relay 3 blocked: No Compressor relay 4 blocked: No </div>		Settings for blocking on cooling relays <ul style="list-style-type: none"> • Compressor relay 1 blocked: Yes/No • Compressor relay 2 blocked: Yes/No • Compressor relay 3 blocked: Yes/No • Compressor relay 4 blocked: Yes/No
Water cooling		
<div style="border: 1px solid black; padding: 5px;"> 08:32 / COOLING COIL  </div>		Shows current status of cooling <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current cooling [%] • Current supply air temperature [°C]
<div style="border: 1px solid black; padding: 5px;"> 08:32 / COOLING COIL  </div>	Shown at Belimo Modbus valve	Cooling interface, Modbus <ul style="list-style-type: none"> • Current valve setting [%] • Absolute position [Feedback] • Test run: Yes/No • Communication: Active / Inactive
<div style="border: 1px solid black; padding: 5px;"> 08:32 / COOLING FORCED CONTROL Cooling: 0.0 V / 0.0 % Supply air temperature: 0.0 °C Timeout: 00:00:00 Forced control: Off Cooling relay 1: Disconnected Motor valve: 0-10V </div>		Forced control of cooling coil Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Current supply air temperature [°C] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Current status Cooling relay 1: Open/closed • Set motor valve's regulation area [2-10V = VEX4000 standard]

Service menu		
Cooling		Description
 <p>08:32 PUMP OPERATION Outdoor air temp. STOP</p>		Set pump operation Pump operation can be set to: <ul style="list-style-type: none"> • Constant operation • Auto • Outdoor air temperature • Cooling requirement Start appears when pump is in operation.
 <p>08:32 PUMP START 21.0 °C STOP</p>	Shown if outdoor temperature is selected	Set pump start temperature <ul style="list-style-type: none"> • The pump starts when the outdoor temperature is higher than the set value. [°C] Start appears when pump is in operation.
 <p>08:32 PUMP START COOLING 25.0% STOP</p>	Shown if cooling requirement is selected	Set pump start cooling requirement <ul style="list-style-type: none"> • The pump starts when the outdoor temperature is lower than the set value. [%] Start appears when pump is in operation.
External DX Cooling		
 <p>08:32 EXTERNAL COOLING COIL 0.0 °C Cooling: 0.0 % 0.0 °C</p>		Shows current status of external cooling <ul style="list-style-type: none"> • Current outdoor temperature [°C] • Current cooling [%] • Current supply air temperature [°C]
 <p>08:32 COOLING FORCED CONTROL Cooling: 0.0 V/ 0.0 % Supply air temperature: 0.0 °C Timeout: 00:00:00 Forced control: Off Cooling relay 1: Disconnected Motor valve: 0-10V</p>		Forced control of external cooling coil Forced operation is only possible once the unit has started. <ul style="list-style-type: none"> • Set forced operation setpoint [%] • Current supply air temperature [°C] • Set remaining time until forced operation terminates [hh:mm:ss] • Activate forced operation: On/ Off • Current status Cooling relay 1: Open/closed • Set motor valve's regulation area [2-10V = VEX4000 standard]
 <p>08:32 EXTERNAL DX COOLING 1 Regulation: 4 step 1 step modulating: No Cooling error: No Cooling output: 0.0 V Minimum airflow: 2800 m³/h Aftercooling time: 60Sec.</p>		Set regulation for current type DX cooling. <ul style="list-style-type: none"> • Set regulation form: <ul style="list-style-type: none"> • 1-step (VEX4000 standard) • 1. Step modulating: Yes/No (No = VEX4000 standard) • Current cooling error: Yes / No • Current signal at cooling output [V] • Set min. airflow for cooling [m³/h] • Set condenser aftercooling [s]
 <p>08:32 EXTERNAL DX COOLING 2 Cooling relay 1: Open Cooling relay 2: Open Cooling relay 3: Open Cooling relay 4: Open</p>		Shows current status of cooling relay <ul style="list-style-type: none"> • Current status Cooling relay 1: Open/closed • Current status Cooling relay 2: Open/closed • Current status Cooling relay 3: Open/closed • Current status Cooling relay 4: Open/closed







Service menu	
Cooling	Description
08:32 / EXTERNAL DX COOLING 3 Cooling error comp. 1: No Cooling error comp. 2: No Cooling error comp. 3: No Cooling error comp. 4: No	Shows current status of cooling compressors <ul style="list-style-type: none"> • Current cooler errors compressor 1: Yes/No • Current cooler errors compressor 2: Yes/No • Current cooler errors compressor 3: Yes/No • Current cooler errors compressor 4: Yes/No
08:32 / EXTERNAL DX COOLING 4 Min. cooling time: 0 Sec. Cooling time relay 1: 0 Sec. Cooling time relay 2: 0 Sec. Cooling time relay 3: 0 Sec. Cooling time relay 4: 0 Sec.	Settings for connection times on cooling relays <ul style="list-style-type: none"> • Set min. cooling time [sec] • Current cooling time relay 1 [sec] • Current cooling time relay 2 [sec] • Current cooling time relay 3 [sec] • Current cooling time relay 4 [sec]
08:32 / EXTERNAL DX COOLING 5 Max. restart/hour: 10/h Restarting relay 1: 0/h Restarting relay 2: 0/h Restarting relay 3: 0/h Restarting relay 4: 0/h	Settings for restart times on cooling relays <ul style="list-style-type: none"> • Set max number restarts per hour • Current number restarts relay 1 • Current number restarts relay 2 • Current number restarts relay 3 • Current number restarts relay 4
08:32 / EXTERNAL DX COOLING 6 Min. stop time: 600Sec. Stop time, relay 1: 0 Sec. Stop time, relay 2: 0 Sec. Stop time, relay 3: 0 Sec. Stop time, relay 4: 0 Sec.	Settings for stop times on cooling relays <ul style="list-style-type: none"> • Set min. stop time [sec] • Current stop time relay 1 [sec] • Current stop time relay 2 [sec] • Current stop time relay 3 [sec] • Current stop time relay 4 [sec]

4.1.6 Damper





Service menu		
Damper	Description	
	DAMPER Show current operating status. Set functions and forced fan control of damper.	
Submenu	Any comments	
Outdoor air damper		
		Outdoor air damper, status <ul style="list-style-type: none"> Current damper position: Open/closed Current supply air [m3/h] [l/s]
	Shown at Belimo Modbus damper motor	Damper motor, Modbus <ul style="list-style-type: none"> Current damper setting [%] Absolute position [Feedback] Test run: Yes/No Communication [Active] / [Inactive]
	Shown only in case of modulating damper motor	Set outdoor air damper <ul style="list-style-type: none"> Current damper setting [%] Set correction factor Set offset [V] Current supply air [m3/h] [l/s]
	Shown only in case of modulating damper motor	Override outdoor air damper Overriding is only possible once the unit has started. <ul style="list-style-type: none"> Set remaining time until overriding terminates [hh:mm:ss] Activate override: On/ Off Set override operation setpoint [V] Current supply air [m3/h] [l/s]
Extract air/Exhaust air damper		
		Extract air damper, status <ul style="list-style-type: none"> Current damper position: Open/closed Current extract air [m3/h] [l/s]
	Shown at Belimo Modbus damper motor	Damper motor, Modbus <ul style="list-style-type: none"> Current damper setting [%] Absolute position [Feedback] Test run: Yes/No Communication [Active] / [Inactive]
	Shown at Belimo Modbus damper motor Shown only if modulated recirculation is configured	Damper motor, Modbus <ul style="list-style-type: none"> Current damper setting [%] Absolute position [Feedback] Test run: Yes/No Communication [Active] / [Inactive]

Service menu		
Damper		Description
	<p>Shown only in case of modulating damper motor</p> <p>Shown only if modulated recirculation is configured</p>	<p>Exhaust air damper, status</p> <ul style="list-style-type: none"> Current damper position: [%] Current supply air [m3/h] [l/s]
Recirculation damper		
		<p>Recirculation damper, status</p> <ul style="list-style-type: none"> Current damper position: Open/closed Current supply air [m3/h] [l/s]
	<p>Shown at Belimo Modbus damper motor</p>	<p>Damper motor, Modbus</p> <ul style="list-style-type: none"> Current damper setting [%] Absolute position [Feedback] Test run: Yes/No Communication [Active] / [Inactive]
	<p>Shown only in case of modulating damper motor</p>	<p>Set recirculation damper</p> <ul style="list-style-type: none"> Current damper setting [%] Set correction factor Set offset [V] Current supply air [m3/h] [l/s]
	<p>Shown only if modulated recirculation is configured</p>	<p>Set I-time for modulated recirculation</p> <ul style="list-style-type: none"> P-band VOC/CO2 [ppm] Set I-time VOC/CO2 [sec] Set I-time temperature [s]
	<p>Shown only if modulated recirculation is configured</p>	<p>Set gain factor for modulated recirculation</p> <ul style="list-style-type: none"> Set gain factor
Smoke-evacuation damper		
		<p>Damper motor, Modbus</p> <ul style="list-style-type: none"> Current damper setting [%] Absolute position [Feedback] Test run: Yes/No Communication: Active / Inactive
		<p>Override smoke-evacuation damper</p> <ul style="list-style-type: none"> Current damper setting [%] Set remaining time until overriding terminates [hh:mm:ss] Override: On/ Off

4.1.7 Temperature sensor correction

Service menu		
Temperature sensor correction		Description
		Settings for sensor correction/calibration For correction of measurement errors, cable resistance and sensor tolerances.
Submenu	Any comments	
	Shown if heating coil 1 is configured	Calibrate temperature measurement - Heating coil 1 Set sensor offset [+/-3.5°C] <ul style="list-style-type: none"> Shows current sensor temperature [°C] Set calibration value [°C]
	Shown if heating coil 2 is configured	Calibrate temperature measurement - Heating coil 2 Set sensor offset [+/-3.5°C] <ul style="list-style-type: none"> Shows current sensor temperature [°C] Set calibration value [°C]
	Shown if water cooling is configured	Calibrates temperature measurement - Water cooling Set sensor offset [+/-3.5°C] <ul style="list-style-type: none"> Shows current sensor temperature [°C] Set calibration value [°C]
	Shown if outdoor sensor is configured	Calibrates temperature measurement - outdoor temperature sensor Set sensor offset [+/-3.5°C] <ul style="list-style-type: none"> Shows current sensor temperature [°C] Set calibration value [°C]
	Up to 4 additional sensors can be configured	Calibrates temperature measurement - Addition sensor Set sensor offset [+/-3.5°C] <ul style="list-style-type: none"> Shows current sensor temperature [°C] Set calibration value [°C]

4.1.8 Pressure transmitter

Service menu		
Pressure transmitter		Description
		Calibration of pressure transmitters Zero-calibrate all pressure transmitters in the air handling unit.
Submenu	Submenu	
		Select type 0 calibration <ul style="list-style-type: none"> • Set zero calibration: [Manual/Auto] If Auto is selected, zero calibration is carried out automatically every time the unit stops.
		Start zero-calibration Confirm to start zero calibration, or press Esc to abort. During zero calibration the unit will stop for about 5 min. 5 min.
		Zero calibration is being performed Acknowledgement that zero calibration is in progress/is complete.

5. Alarm summary

Alarm list manual terminal

Alarm list EXcon SW version 3.13

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
1	A	3	N/A			Fire alarm
2	A	3	N/A		X	External fire thermostat
3	A	3	N/A		X	Fire alarm
4	B	3	N/A	X	X	External stop
7	A	3	N/A	X	X	Supply air EC controller: No communication
8	A	3	N/A	X	X	Extract air EC Contrl. No communication
9	B	1200	N/A	X		Airflow compensation of filter monitor Not measured
10	B	3	N/A	X		No communication with manual terminal
11	A	3	N/A	X	X	No communication with FanIO 1
12	A	3	N/A	X	X	No communication with FanIO 2
13	A	3	N/A	X	X	No communication with expansion module 1
14	A	3	N/A	X	X	No communication with expansion module 2
15	B	3	N/A	X		No communication with LON gateway
16	A	3	N/A	X	X	No communication with supply air frequency converter
17	A	3	N/A	X	X	No communication with extract frequency converter
18	A	3	N/A	X	X	No communication with rotary heat exchanger
19	A	3	N/A	X	X	Pressure transmitter (PTH): No communication
20	A	10	N/A	X	X	Supply air, temperature sensor triggered
21	A	10	N/A	X	X	Extract air, temperature sensor alarm triggered
22	A	10	N/A	X	X	Room temperature sensor alarm triggered.
23	A	10	N/A	X	X	Exhaust air, temperature sensor alarm triggered
24	A	10	N/A	X	X	Outdoor air, temperature sensor alarm triggered
25	A	10	N/A	X	X	Water heating coil, temperature sensor alarm triggered
26	A	10	N/A	X	X	Heat recovery, temperature sensor alarm triggered
27	A	10	N/A		X	Pump alarm, heating
28	A	3	N/A		X	Frost alarm, Water heating coil
30	A	3	N/A		X	Supply air frequency converter low supply voltage (Vlo)
31	A	3	N/A		X	Supply air frequency converter High supply voltage (Vhi)
32	A	3	N/A		X	Supply frequency converter High output current (Ihi)
33	A	3	N/A		X	Supply frequency converter High temperature (Thi)
34	A	3	N/A		X	Supply frequency converter Loss of supply phase
35	B	3	N/A			Supply frequency converter High internal ripple voltage
37	A	3	N/A		X	Supply air fan, alarm
38	B	600	N/A			Supply air filter, alarm

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
39	A	10	N/A		X	FanIO 1: +24 VDC overloaded
40	A	3	N/A		X	Extract frequency converter Low supply voltage (Vlo)
41	A	3	N/A		X	Extract frequency converter High supply voltage (Vhi)
42	A	3	N/A		X	Extract frequency converter High output current (Ihi)
43	A	3	N/A		X	Extract frequency converter High temperature (Thi)
44	A	3	N/A		X	Extract frequency converter Loss of supply phase
45	B	3	N/A			Extract frequency converter High internal ripple voltage
47	A	600	N/A		X	Exhaust air/extract air fan, alarm
48	B	10	N/A			Extract air filter, alarm
49	A	3	N/A		X	FanIO 2: +24 VDC overloaded
50	B	3	N/A			Rotary heat exchanger No rotation
51	B	3	N/A			Rotary heat exchanger Low supply voltage (Vlo)
52	B	3	N/A			Rotary heat exchanger High supply voltage (Vhi)
53	B	3	N/A			Rotary heat exchanger High output current (Ihi)
54	B	3	N/A			Rotary heat exchanger High internal temperature
55	B	3	N/A			Rotary heat exchanger Torque overload
58	A	300	N/A		X	Frost alarm heat exchanger
59	A	600	N/A		X	No heat recovery. Low temperature
60	A	600	SP-10°C		X	Low supply air temperature
61	B	600	SP+5°C			High supply air temperature
62	B	1200	SP-10°C			Low extract air temperature
63	B	1200	SP+5°C			High extract air temperature
65	B	300	N/A	X		Heating cut out due to low airflow
66	B	3	N/A			Electric heating coil: Overheating alarm
67	B	3	N/A			Reduced airflow
68	B	3	N/A			Contact for Electric heating coil is stuck
70	B	1200	N/A	X		High VOC/CO2
71	A	600	SP-10°C		X	Low supply airflow
72	A	600	SP+10%		X	High supply airflow
73	A	600	SP-10°C		X	Low extract airflow
74	A	600	SP+10%		X	High extract airflow
75	B	600	SP-10°C			Low supply air pressure
76	A	600	SP+10%		X	High supply air pressure
77	B	600	SP-10°C			Low extract air pressure
78	A	600	SP+10%		X	High extract air pressure
80	B	3	N/A			Cooling error
81	B	3	N/A			Low cooling pressure circuit 1
82	B	3	N/A			High cooling pressure circuit 1
83	B	3	N/A			Cooling error 1: Compressor 1 overheated circuit 1

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
84	B	3	N/A			Cooling error 2: Compressor 2 overheated circuit 1
85	B	3	N/A			Low cooling pressure circuit 2
86	B	3	N/A			High cooling pressure circuit 2
87	B	3	N/A			Cooling error 3: Compressor 1 overheated circuit 2
88	B	3	N/A			Cooling error 4: Compressor 2 overheated circuit 2
90	B	3	N/A			Pressure transmitter error: DX low pressure 1
91	B	3	N/A			Pressure transmitter error: DX high pressure 1
92	B	3	N/A			Pressure transmitter error: DX low pressure 2
93	B	3	N/A			Pressure transmitter error: DX high pressure 2
94	B	3	N/A	X		VOC/CO2 sensor not configured
95	B	3	N/A	X		FanOpt. supply air not configured
96	B	3	N/A	X		FanOpt. extract air not configured
100	A	3	N/A	X	X	Pressure transmitter 0 (PTH6202): No communication
101	A	3	N/A	X	X	Pressure transmitter 1 (PTH6202): No communication
103	A	3	N/A	X	X	Pressure transmitter 3 (PTH6202): No communication
104	A	3	N/A	X	X	Pressure transmitter 4 (PTH6202): No communication
105	A	3	N/A	X	X	Pressure transmitter 5 (PTH6202): No communication
106	A	3	N/A	X	X	Pressure transmitter 6 (PTH6202): No communication
107	A	3	N/A	X	X	Pressure transmitter 7 (PTH6202): No communication
108	A	3	N/A	X		Expansion module45 1 (Air2Ext45): No communication
109	A	3	N/A	X		Expansion module45 2 (Air2Ext45): No communication
111	B	3	N/A	X		Pressure transmitter, supply air (PTH6202): No communication
112	B	3	N/A	X		Pressure transmitter, extract air (PTH6202): No communication
113	B	10	N/A	X		VOC/CO2 sensor error: VOC/CO2 sensor disconnected/short-circuited
115	A	3	N/A		X	Supply air EC controller: Alarm stop
116	A	3	N/A		X	Supply air EC controller: Rotor blocked
117	B	3	N/A			Supply air EC controller: Power restriction
118	B	3	N/A			Supply air EC controller: Low supply voltage (Vlo)
119	B	3	N/A			Supply air EC controller: High supply voltage (Vhi)
120	B	3	N/A			Supply air EC controller: High temperature (Thi)
121	B	3	N/A			Supply air EC controller: High internal ripple voltage
122	A	3	N/A		X	Extract air EC Contrl. Alarm stop
123	A	3	N/A		X	Extract air EC Contrl. Rotor blocked
124	B	3	N/A			Extract air EC Contrl. Power restriction active
125	B	3	N/A			Extract air EC Contrl. Low supply voltage (Vlo)
126	B	3	N/A			Extract air EC Contrl. High supply voltage (Vhi)
127	B	3	N/A			Extract air EC Contrl. High temperature (Thi)
128	B	3	N/A			Extract air EC Contrl. High internal ripple voltage

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
129	B	3	N/A			Supply air EC Contrl. : Loss of supply phase
130	B	3	N/A			Extract air EC Contrl. Loss of supply phase
131	A	3	N/A	X	X	FanIO 1 (Air2FanIO21): No communication
132	A	3	N/A	X	X	FanIO 2 (Air2FanIO21): No communication
133	A	3	N/A	X	X	Damper motor (supply air), ID 130: No communication
134	A	3	N/A	X	X	Damper motor (exhaust air), ID 131: No communication
135	A	3	N/A	X	X	Damper motor (recirculation), ID 132: No communication
136	A	3	N/A	X	X	Damper motor (heat exchanger), ID 133: No communication
137	A	3	N/A	X	X	Damper motor (drying damper), ID 134: No communication
141	A	3	N/A	X	X	Valve motor (Heating), ID 138: No communication
142	A	3	N/A	X	X	Valve motor (cooling), ID 139: No communication
143	A	3	N/A	X	X	Valve motor (Heating2), ID 140: No communication
144	A	3	N/A	X	X	Valve motor (Heat recovery unit), ID 141: No communication
145	A	3	N/A	X	X	Valve motor (pre-heating), ID 142: No communication
146	A	3	N/A	X	X	Valve motor (6), ID 143: No communication
149	B	10	N/A	X		Damper motor (supply air): Unable to reach setpoint
150	B	10	N/A	X		Damper motor (exhaust air): Unable to reach setpoint
151	B	10	N/A	X		Damper motor (recirculation): Unable to reach setpoint
152	B	10	N/A	X		Damper motor (heat exchanger): Unable to reach setpoint
153	B	10	N/A	X		Damper motor (drying damper): Unable to reach setpoint
157	B	10	N/A	X		Valve motor (Heating): Unable to reach setpoint
158	B	10	N/A	X		Valve motor (cooling): Unable to reach setpoint
159	B	10	N/A	X		Valve motor (heating 2): Unable to reach setpoint
160	B	10	N/A	X		Valve motor (Heat recovery unit): Unable to reach setpoint
161	B	10	N/A	X		Valve motor (pre-heating): Unable to reach setpoint
162	B	10	N/A	X		Valve motor (6): Unable to reach setpoint
166	B	360	N/A			Fire damper not closed
167	B	360	N/A			Fire damper not open
168	B	300	N/A	X		Heating 2 cut out due to low airflow
169	B	30	N/A			Electric heating coil 2: overheating alarm
170	B	30	N/A			Contactors for electric heating coil 2 is stuck
171	A	10	N/A	X	X	Temperature sensor error: Water heating coil 2
172	A	10	N/A		X	Pump alarm: Water heating coil 2
173	A	3	N/A		X	Frost alarm: Water heating coil 2
174	A	10	N/A	X	X	Temperature sensor error: combi-coil
175	A	10	N/A		X	Pump alarm: Combi-coil
176	A	3	N/A		X	Frost alarm: Combi interface (heating)
177	A	3	N/A		X	Frost alarm: Combi interface (cooling)
178	B	10	N/A			Alarm from heat exchanger or circulation pump

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
179	B	10	N/A	X		Temperature sensor error: Heat pump
180	A	10	N/A		X	Frost alarm, Air
194	B	10	N/A	X		No communication, Modbus, HTH-6202, sensor
195	B	10	N/A	X		No communication, Modbus, HTH-6203, sensor
196	B	10	N/A	X		Output, humidifier not configured
197	B	10	N/A	X		Alarm input from humidifier
198	B	1200	N/A	X		High humidity in supply air
199	B	1200	N/A	X		Low humidity in supply air
200	B	1200	N/A	X		High humidity in supply air
201	B	1200	N/A	X		Low humidity in supply air
202	B	10	N/A	X		Supply temp. cooling coil, sensor alarm
203	A	3	N/A	X	X	Expansion module 3: No communication
204	A	3	N/A	X	X	Expansion module 4: No communication
205	A	3	N/A	X	X	Expansion module 5: No communication
206	A	3	N/A	X	X	Expansion module 6: No communication
207	A	3	N/A	X	X	Expansion module 7: No communication
208	B	3	N/A	X		Room control: No communication
209	B	3	N/A	X		VTH-6202, VOC sensor No communication
210	B	600	N/A	X		VTH-6202, VOC sensor error, measured value outside range
211	B	10	N/A	X		No communication, HTH-6204, humidity sensor
212	B	10	N/A	X		Dew point sensor error
213	B	300	N/A	X		INACTIVE
214	A	3	N/A	X	X	Expansion module 8: No communication
215	B	30	N/A	X		Contactors for electrical pre-heating coil stuck
216	B	30	N/A	X		Preheater: Overheating alarm
217	A	10	N/A	X	X	Preheater: Water heating coil, sensor error
218	A	10	N/A		X	Preheater: Pump alarm:
219	A	3	N/A		X	Preheater: Frost alarm
220	A	10	N/A	X	X	Preheater: Airflow sensor error
221	B	300	N/A	X		Preheater: Reduced output
222	B	300	N/A	X		Heat recovery efficiency is less than minimum setpoint
223	A	3	N/A	X	X	Supply air frequency converter (ATV) No communication
224	A	3	N/A	X	X	Extract air frequency converter (ATV) No communication
225	B	10	N/A			ATV supply air frequency converter error
226	B	10	N/A			ATV extract air frequency converter error
231	B	1200	N/A	X		Dynamic pressure control cannot be used
232	B	3	N/A	X		PTH sensor (extract air/exhaust air) rotary heat exchanger not configured
233	B	1800	N/A	X		Rotary heat exchanger iced up

Alarm no	Alarm type	Alarm delay secs	Alarm limit	Auto reset	Machine stop	Alarm text - Handheld terminal
234	B	1800	N/A			Rotary heat exchanger is soiled
235	A	3	N/A		X	Supply air, EC-2 controller: Alarm stop
236	A	3	N/A		X	Supply air, EC-2 controller: Rotor blocked
237	B	3	N/A			Supply air, EC-2 controller: Power restriction
238	B	3	N/A			Supply air, EC-2 controller: Low supply voltage (Vlo)
239	B	3	N/A			Supply air, EC-2 controller: High supply voltage (Vhi)
240	B	3	N/A			Supply air, EC-2 controller: High temperature (Thi)
241	B	3	N/A			Supply air, EC-2 controller: High internal ripple voltage
242	A	3	N/A		X	Extract air, EC-2 controller: Alarm stop
243	A	3	N/A		X	Extract air, EC-2 controller: Rotor blocked
244	B	3	N/A			Extract air, EC-2 controller: Power restriction active
245	B	3	N/A			Extract air, EC-2 controller: Low supply voltage (Vlo)
246	B	3	N/A			Extract air, EC-2 controller: High supply voltage (Vhi)
247	B	3	N/A			Extract air, EC-2 controller: High temperature (Thi)
248	B	3	N/A			Extract air, EC-2 controller: High internal ripple voltage
249	B	3	N/A			Supply air, EC-2 controller: Loss of supply phase
250	B	3	N/A			Extract air EC-2 Contr.:No supply phase
251	A	3	N/A	X	X	Supply air, EC-2 controller: no communication
252	A	3	N/A	X	X	Extract air, EC-2 controller: No communication
253	B	3	N/A			Temperature sensor (HTH6202): No communication
254	B	3	N/A			Temperature sensor (HTH6203): No communication
255	B	3	N/A			Supply airflow correction, temperature sensor error
256	B	10	N/A	X		Temperature sensor error: Supplementary sensor 1
257	B	10	N/A	X		Temperature sensor error: Supplementary sensor 2
258	B	10	N/A	X		Temperature sensor error: Supplementary sensor 3
259	B	10	N/A	X		Temperature sensor error: Supplementary sensor 4
260	B	3	N/A		X	Supply air motor control has wrong type no or is defective
261	B	3	N/A		X	Supply air motor control 2 has wrong type no or is defective
262	B	3	N/A		X	Supply air motor control 1 has wrong type no or is defective
263	B	3	N/A		X	Supply air motor control 2 has wrong type no or is defective



Scan code and go to addresses at
www.exhausto.com