


VEX100CF RANGE COUNTER FLOW HEAT EXCHANGER

# Electrical installation guide for VEX140CF-X for third-party control systems



RD1487-01

⚡ Electrical installation.....Chapter 1 + 2

Original instructions



**1. Connection of voltage supply**

**1.1. Connection diagram for VEX with motor control (MC).....4**


1.1.1. Alarm relay function.....6




**2. Installation of the VEX**

**2.1. Scope of installation.....7**

## Symbols, terms and warnings

**Prohibition symbol**  Failure to observe instructions marked with a prohibition symbol may result in serious or fatal injury.


**Danger symbol**  Failure to observe instructions marked with a danger symbol may result in personal injury and/or damage to the unit.

**Isolation switch**  In accordance with The Machinery Directive\*, an isolation switch must be permanently installed in the unit.

The isolation switch must:

- be lockable or positioned in plain sight in the immediate vicinity of the unit
- disconnect all poles from the supply voltage
- be constructed in accordance with EN 60204-1


The isolation switch is **not** supplied by EXHAUSTO.

**Warnings**  The work must be performed by an authorised electrician, in accordance with locally applicable regulations and legislation.

**Lock the air handling unit during operation**

The VEX unit must always be locked during operation:

- Use the cylinder lock in the handle. **Remember** to remove the key from the lock.
- Or use a padlock. Use the handle's built-in padlock fixture.



**Information plate**

The VEX unit rating plate shows:

- VEX unit, type (1)
- production number (2)

EXHAUSTO		CE	
Type	V150CFHLECW2	1	10kA
	No./Year 2406294/2017	2	
Supply	Voltage: 3x400V+N+PE ~50Hz	Current:	15A
Heat	HCW		
FAN ECO design	$\eta_1 = 60,0\%$ (A) N62 (2015) N = 74,4 VSD integrated		

**NB:** Always have the production number ready when contacting EXHAUSTO A/S.




# 1. Connection of voltage supply

## 1.1 Connection diagram for VEX with motor control (MC)

Diagram, 1 x 230 V

The diagram below illustrates connection of the supply voltage to the motor control and bypass damper.



### Key to diagram

Designation	Description
MC1	Control signal for motor control M1 (exhaust air/extract air)
MC2	Control signal for motor control M2 (supply air/outdoor air)
BP1	Control signal for bypass damper 1 (supply air/outdoor air)
MC1 Supply	Power supply for motor control MC1 (exhaust air/extract air)
MC2 Supply	Power supply for motor control MC2 (supply air/outdoor air)

RD13487-01

**NB** Other parts, shown on the front page of the VEX instructions, are supplied by EXHAUSTO

---

**Electrical data** The following table shows the max. phase current.

Type	Supply voltage	Max. Phase current (total)	MC1 phase current	MC2 phase current
VEX140	1 x 230 V + N+ PE	10 A	5 A	5 A

**NB** Power consumption is taken from one phase and is not sinusoidal.

---

1.1.1 Alarm relay function

Description		Drawing
<b>Connection</b>	The diagram shows which two terminals from MC are connected to the terminal block in the connection box	<p>Alarmrelay MC</p> <p>Connection box</p> <p>5450255GB-01</p> <p>MC: terminal 13-14 and terminal 19-20</p>
<b>Function</b>	The alarm relay position in the case of power failure or similar	<p>Power off</p>
	The alarm relay position in case of alarm	<p>Alarm</p>
	The alarm relay position during operation	<p>Power on, No alarm</p>



## 2. Installation of the VEX

### 2.1 Scope of installation

**VEX unit** The electrical installation for the VEX unit comprises the following tasks:

**Connection box** Wiring configurations for the terminal board in the connection box:

- Supply voltage to motors and motor control (MC)
- Control signals for motor control (MC) and alarm relay
- Control signal to bypass damper

**NB** • The motor control is pre-programmed by EXHAUSTO and has overload protection

- The motor control must have short-circuit protection

For other technical data, see the "Technical data" section in the main instructions of the VEX.

**Bypass damper function** When connecting bypass damper to the control signal, the following must be taken into consideration:

Control voltage to BP1	Function
2 V	100% heat recovery. Outdoor air is led through the counterflow heat exchanger.
7.8 V	0% heat recovery. The outdoor air bypasses the counterflow heat exchanger.



Scan code and go to addresses at  
[www.exhausto.com](http://www.exhausto.com)