


Ventilator diagram

1. DTH16041EC, DTH20041EC, DTV16041EC, DTV20041EC, VVR16041EC, VVR20041EC, BESF14641EC

Diagram



Key to diagram

Terminal		
EX-DV1001	EFC1P/EFC1P2 Panel	Signal description
1	3	GND
2	4	0-10V
3		Modbus A
4		Modbus B
5		GND
6	5	+12V
7		Dig_in3
8		RL_NC
9	B	RL_C
10	A	RL_NO
11		GND
12		Dig_in2
13		GND
14	2	Dig_in1