

	
	
	<p>VEX340</p>
<p> <input type="radio"/> GB Total weight of the unit <input type="radio"/> DK Aggregatets total vægt <input type="radio"/> DE Gesamtgewicht des Gerätes <input type="radio"/> NO Aggregatets totalvekt <input type="radio"/> SE Aggregatets totalvikt <input type="radio"/> NL Totaal gewicht van het apparaat <input type="radio"/> FI Koneen kokonaispaino </p>	<p>450 kg</p>

- GB Do not push the unit across the foundation - It may cause damage to the base feet!
 DK Skub ikke aggregatet hen over underlaget - sokkelfødderne kan blive beskadiget!
 DE Das Gerät bitte nicht über die Bettung schieben - die Sockelfüße könnten dadurch beschädigt werden!
 NO Skyv ikke aggregatet over underlaget - maskin føttene kan bli skadet.
 SE Skjut inte aggregatet över underlaget utan att lyfta det först - sockelfötterna kan skadas.
 NL De unit niet over de vloer schuiven - Het kan beschadiging van de stelvoeten veroorzaken!
 FI Älä työnnä konetta alustalla – koneen jalusta voi vahingoittaa!